

R-9035

ANTI-SUBMARINE STRAP MOUNT
(FOR AFTERMARKET SEATS)
In 911(1984-1998)

INSTALLATION INSTRUCTIONS

This mount has been designed to provide a mounting point for an anti-submarine strap in 911(1984-1998) models.

Additional Required Hardware:

§ One-piece racing seats with anti-sub strap pass-through (Standard reclining factory seats WILL NOT work)

Step1.

With Brey-Krause side mount brackets on sliders per installation instructions, position R-9030 anti-submarine strap bar with fire extinguisher mounting tabs facing front onto (4) mounting studs located on the sliders as shown.



Step 2.

Use original factory nuts (loctite is recommended), to hold the bar in place. Make sure sliders are parallel and 16" apart before tightening nuts.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.